



БЛОКИ МОНТАЖНЫЕ


G 10S, 102S

ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

По вопросам продаж и поддержки обращайтесь:


Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астана +7(7172)727-132	Калуга (4842)92-23-67	Омск (3812) 21-46-40	Ставрополь (8652)20-65-13
Астрахань (8512) 99-46-04	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462) 77-98-35
Барнаул (3852) 73-04-60	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Белгород (4722)40-23-64	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Владивосток (423)249-28-31	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Волгоград (844)278-03-48	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Вологда (8172)26-41-59	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Воронеж (473)204-51-73	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212) 92-98-04
Екатеринбург (343)384-55-89	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Иваново (4932)77-34-06	Набережные Челны (8552)20-53-41	Севастополь (8692) 22-31-93	Череповец (8202)49-02-64
Ижевск (3412)26-03-58	Нижний Новгород (831)429-08-12	Симферополь (3652) 67-13-56	Ярославль (4852)69-52-93
Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54	

сайт: oteco.nt-rt.ru || эл. почта: oce@nt-rt.ru




OTECO (6) ROLLER
G-10-S & G-102-S
WIRE LINE GUIDE


GF-32
Angle



GF-34
GF-36
Beam



GF-37
Beam



GF-33
Angle

ITEM DESCRIPTION	MAXIMUM WIRELINE	OTECO ITEM #	WEIGHT	
			Lbs	(kg)
G-10-S WIRE LINE GUIDE ASSEMBLY WITH (6) ROLLERS	1-1/2"	431101	65	(29.5)
G-102-S WIRE LINE GUIDE ASSEMBLY WITH (6) ROLLERS	2"	431122	63	(28.6)

Replacement parts for OTECO G10S/G102S, BJ Roliguide and Turnback assemblies on back of page.

MOUNTING BRACKET INFORMATION

ITEM DESCRIPTION	MAST TYPE	BEAM SIZE	LENGTH	ADJUSTMENTS		3/8" CABLE		OTECO ITEM#	Wt. LBS
				HOLES	SPACING	TRI	DROP		
HANGING ASSY,GF-32	ANGLE	6"x5-1/2"x3/8"	FLUSH MOUNT	BRACKET		60'	4'-4"	431932	48
HANGING ASSY,GF-33	ANGLE	6" to 8"	3' - 0"	5	1-1/4"	62'	6'-4"	431933	107
HANGING ASSY,GF-34	BEAM	8"x10-3/4"	4' - 7"	5	1-1/4"	65'	4'-4"	431934	107
HANGING ASSY,GF-36	BEAM	12-1/4"x12-3/4"	3' - 9 3/4"	5	1-1/4"	63'	4'-4"	431936	104
HANGING ASSY,GF-37	BEAM	WELDED	TELESCOPE	5	3"	58'	4'-4"	431937	160

Wire Line Guide Hanging assemblies utilize 3/8" wire cable.

Assemblies include: mounting brackets & hardware, 3/8" tri-wire cable, pulleys and drop cable assembly.

3/8" wire cable Support Line not included in assemblies.

All assemblies utilize (3) HF-4 hayfork pulleys.

All assemblies listed use triangular method.



По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Новосибирск (383)227-86-73	Сочи (862)225-72-31
Астана +7(7172)727-132	Калуга (4842)92-23-67	Омск (3812) 21-46-40	Ставрополь (8652)20-65-13
Астрахань (8512) 99-46-04	Кемерово (3842)65-04-62	Орел (4862)44-53-42	Сургут (3462) 77-98-35
Барнаул (3852) 73-04-60	Киров (8332)68-02-04	Оренбург (3532)37-68-04	Тверь (4822)63-31-35
Белгород (4722)40-23-64	Краснодар (861)203-40-90	Пенза (8412)22-31-16	Томск (3822)98-41-53
Брянск (4832)59-03-52	Красноярск (391)204-63-61	Пермь (342)205-81-47	Тула (4872)74-02-29
Владивосток (423)249-28-31	Курск (4712)77-13-04	Ростов-на-Дону (863)308-18-15	Тюмень (3452)66-21-18
Волгоград (844)278-03-48	Липецк (4742)52-20-81	Рязань (4912)46-61-64	Ульяновск (8422)24-23-59
Вологда (8172)26-41-59	Магнитогорск (3519)55-03-13	Самара (846)206-03-16	Уфа (347)229-48-12
Воронеж (473)204-51-73	Москва (495)268-04-70	Санкт-Петербург (812)309-46-40	Хабаровск (4212) 92-98-04
Екатеринбург (343)384-55-89	Мурманск (8152)59-64-93	Саратов (845)249-38-78	Челябинск (351)202-03-61
Иваново (4932)77-34-06	Набережные Челны (8552)20-53-41	Севастополь (8692) 22-31-93	Череповец (8202)49-02-64
Ижевск (3412)26-03-58	Нижний Новгород (831)429-08-12	Симферополь (3652) 67-13-56	Ярославль (4852)69-52-93
Казань (843)206-01-48	Новокузнецк (3843)20-46-81	Смоленск (4812)29-41-54	

сайт: oteco.nt-rt.ru || эл. почта: oce@nt-rt.ru